

ADVANTAGE - 2000+

Installation Instructions :

2391-BP : Inside Corner Back Panel & Cover

Mounting Back Panels to uprights :

STEP (1) : On the same column of vertical mounting holes as the Braces start a screw into the mounting holes directly above the brace mounting at each end, leaving approx. 3/16" of threads exposed. Place the Back Panel onto the screws using the 2 keyed holes in the bottom of the Back Panel at each end. Be sure that the Back Panel is seated onto the 2 screws into the keyed hole.

STEP (2) : Push the Back Panel against the back of the uprights to be even with the Braces. Place screws into the 2 remaining mounting holes at the top corners of the Back Panel. **Secure Back Panel by tightening all 4 mounting screws for each Back Panel.** Mount the Cover Panel over the Back Panel and seat firmly against the magnetic strips.

