

**Installation Instructions :**

**#2540-PT: Adjustable Phone Tray - Complete**

**STEP - 1 :** Install the Mounting Tab (#2540-PT-6102) to the Phone Tray (#2540-PT-6101) using two standard screws (#12-24x 1/2"lg.) into the threaded holes in the back of the phone tray. There are three horizontal mounting positions on the back of the phone tray. The mounting tab can be reversed which would allow the tray to have 6 horizontal mounting locations.

**STEP - 2 :** Mount the phone tray assembly to the Frame Uprights using two standard screws. The assembly can be adjusted vertically in 1" increments. The assembly can be tilted up or down depending on which screw hole is used. See sketch.

