

ADVANTAGE - 2000+

Installation Instructions :

- # 2226-CT : 26"* wide Countertop - Laminated
- # 2250-CT : 50"* wide Countertop - Laminated
- # 2272-CT : 72"* wide Countertop - Laminated
- # 2291-CT : Inside Corner Countertop - Laminated
- # 2292-CT : Outside Corner Countertop - Laminated

*nominal

Mounting Countertop to uprights :

STEP (1): Lay the countertop down with the bottom facing up. Mount the cantilevered shelf brackets to the countertop into the threaded holes marked 'M' with the screws provided (#12-24x1/2" lg.). Use the straight edge of the shelf bracket to mount to the countertop being sure that the smooth edge of the brackets are facing the outside of the shelf and the mounting ears are both opposite the leading radius edge of the countertop.

STEP (2): On the mounting holes under the tilt shelf count down 3" from the tilt shelf front mounting screw & start a std. screw (as shown in detail), then start another screw 3" down from that. Do the same on the inside of the other upright of which you wish to mount the countertop. Lift the countertop & bracket assembly onto the screws. The countertop & brackets will slide onto the screws and fall into place. **Lock the countertop into place by placing std. screws into the remaining of the (3) bracket screw hole locations and tighten all screws!**

Corner countertops: Installing the corner countertops do the steps in reverse. Mount the brackets to the frame & then the corner countertop to the brackets.

All countertops can be networked together when side by side at the same height with one standard screw through the right side of the countertop to the adjoining countertop.

